WATER NOTES:

- 1. All water mains shall be AWWA C900 (class 150 or greater).
- 2. Water services shall be single 1" copper tubing.
- 3. Water line is to be constructed in accordance with the NBU Systems Connection & Construction Policy.
- 4. Water main shall have a minimum of 42 inches of cover, otherwise concrete encasement will be required.
- 5. Each unit in a duplex, triplex, fourplex, or condominium shall be provided with an individual water meter. A master meter can be considered for separate buildings, however, those buildings must be plumbed to allow separate meters for future consideration.
- 6. Contractor will keep the area on top of and around the water meter box free of all objects and debris.
- 7. Initial backfill of water lines shall be manufactured sand or pea gravel as per NBU Systems Connection & Construction Policy.
- 8. Secondary backfill of water lines shall generally consist of material removed from the trench and shall be free from brush, debris and trash or stones having any dimension larger than 6" inches at the largest dimension.
- 9. Hydrostatic testing is done from valve to valve.
- 10. No meter boxes to be set in driveways or sidewalks. Any meter boxes set in driveways or sidewalks will be relocated at contractor's and/or developer's expense.
- 11. Meter boxes must be set at the proposed grade. Any meter boxes that are not set at the final grade will be adjusted at contractor's and/or developer's expense.
- 12. Acceptable meter boxes are D13-BAMR and D15-BAMR. New residential lots are required to use the D15-BAMR meter boxes (double AMR). Commercial lots should choose which box applies to the domestic and/or irrigation meter layout.
- 13. Thrust blocks will not be allowed on the system without special approval. Joints will be restrained with restraining systems approved by NBU and restraint length shall be submitted to NBU at the time of plan submittal.
- 14. Contractor shall place tracer wire on top of the water mains. Tracer wire should run from valve to valve and exit at the valve box. The tracer wire should be attached to the top of the pipe using tape. Excess wire should be left within valve boxes to be placed within lid of cover.
- 15. Water quality shall be protected with appropriate backflow prevention assemblies installed on all irrigation systems, fire suppression systems and multi-unit complexes along with multi-level properties on the domestic meter containment. NBU can assist with the decision on appropriate backflow assemblies on a case by case basis. Contact NBU backflow prevention specialist for more details. Email questions to crossconnection@nbutexas.com

- 16. All backflow prevention assemblies shall be tested upon installation and report sent to NBU via the online tracking system, contact NBU backflow prevention specialist for more details. Email questions to crossconnection@nbutexas.com
- 17. All residential and commercial properties shall have a Customer Service Inspection certificate (CSI Inspection) completed upon completion of the building or home structure. Contact NBU backflow prevention specialist for more details. Email questions to crossconnection@nbutexas.com