HOW TO READ YOUR SMART WATER METER

- **1. Rate of Flow** Indicates how many gallons of water per minute are flowing through the meter.
- **2. Flow Direction** Indicates which way the water is flowing through the meter.
- **3. Low Battery Alarm** Indicates a low battery and transmits this data to NBU for servicing.
- **4. Leak Alarm** Indicates that there has been a sustained flow through the meter which is suspect of a leak.
- **5. Alert** Indicates a mechanical or electronic issue with the meter.
- **6. Factor** Multiply this number by a daily read difference to determine a gallon total.
- **7. Totalization** Indicates how many gallons have flowed through the meter over its lifetime.
- **8. AMR Digit Highlighter** Helps identify numbers other than placeholders.
- **9. Unit of Measure** NBU water meters read in gallons.





